

2002-2005 correct SRS setup

Bottom Bracket Spindle Length	Typical # of Washers Needed
113	0
116	1
118	2
122	3 or 4
127-128	5

use top hole in top slider
for almost all frames

top slider positioned
at 12-O-Clock

little to no gap
between edge of
slider and Supercharger

washers used under
chainring bolt heads

3mm gap between
lower slider and
Supercharger

